



User's Guide

UT-620

RS232/RS485 To TCP/IP Converter Module

2003

【 Table of Content 】

1. Getting to Know your UT-620	1
1.1 Introduction	
1.2 Main features	
1.3 Applications for UT-620.....	2
2. Hardware Installation & Initial Setup	3
2.1 Hardware Installation	
2.2 LED status.....	4
2.3 Initial Setup	
2.3.1 Installing the TCP/IP Protocol.....	5
2.3.2 Fixed IP Addresses Configuration.....	7
2.3.3 Configure your UT-620.....	9
3. UT-620 Configuration Setup	10
3.1 Operation mode	
3.2 IP Configuration.....	12
3.3 Serial Type.....	14
3.4 Dynamic DNS.....	15
4. UT-620 Management Setup	16
4.1 Device Admin	
4.2 Device Status.....	18
4.3 E-Mail Alert.....	18
4.4 Backup and Restore.....	19
4.5 Upgrade Firmware	
4.6 Ping.....	20
5. Troubleshooting	21
Appendix B: DDNS	
Appendix C: Glossary	28
Appendix D: Finding the MAC Address and IP Address for Your Ethernet Adapter	31

Copyright by UTEK Technology Co., Ltd., all rights reserved.

The information in this document has been carefully checked and is believed to be correct as of the date of publication. UTEK Technology Co., Ltd. reserves the right to make changes in the product or specification, or both, presented in this publication at any time without notice.

UTEK assumes no responsibility or liability arising from the specification listed herein. UTEK makes no representations that the use of its products in the manner described in this publication will not infringe on existing or future patents, trademark, copyright, or rights of third parties. Implication or other under any patent or patent rights of UTEK Technology Co., Ltd grants no license.

All other trademarks and registered trademarks are the property of their respective holders.

1. Getting to Know your UT-620

1.1 Introduction

The UT-620 is a RS232/RS485/RS422 to TCP/IP converter integrated with a robust system and network management features designed for industrial equipment to be accessed and controlled via Intranet or Internet.

By integrating RTOS (Real Time Operating System) and complete TCP/IP protocol stack capability, UTEK's UT-620 provides not only a robust and high performance system to make your device connecting to Network, but also ease installation and Internet access.

The UT-620 Web Configurator is a breeze to operate and totally independent of the operating system platform you use.

1.2 Main features

The following are the main features of UT-620

TCP/UDP server/client support

The UT-620 support four types of connection: TCP server, UDP server, TCP client and UDP client, user can select one of types to meet application requirement.

DHCP Client

DHCP (Dynamic Host Configuration Protocol) client obtains the TCP/IP configuration at start-up from a centralized DHCP server, which means it can get IP address, an IP default gateway and DNS server.

PPP Over Ethernet

PPPoE is a protocol for connecting remote hosts to the Internet over DSL connection by simulating dial-up connection.

Dynamic DNS

With dynamic DNS support, you can have a static hostname alias for a dynamic IP address, allowing the host to be more easily accessible from various locations on the Internet.

Auto-negotiating 10/100Mbps Ethernet

The Ethernet interface automatically detects if it is on a 10 or a 100 Mbps Ethernet.

Full Network Management via Web

This feature allows you to access or manage device through IE or Netscape on any platform. The firmware also can be upgraded via Web browser.

Backup and Restore configuration

This feature allows you to backup system configuration to a file and restores it, for the security issue, the file which backup from system is an encryption format.

IO Controller

The UT-620 supports 3 DI/3 DO totally; 3 DI with any combination rule can trigger each DO. By providing a smart and easily setup way via Web, user doesn't need to have any programmer background.

Alarm Generation

With SMTP client support, you can set system to trigger alarm message via e-mail or SMS (Short Message System) to your mobile phone.

1.3 Applications for UT-620




Figure 1 Standalone UT-620's application through Internet



Figure 2 Socket-Type UT-620's application through Internet

2. Hardware Installation & Initial Setup

2.1 Hardware Installation



2.2 LED status

LED	Color(s)	Activity	Desc.
PWR	Red	Off	Power OFF
		Red Blinking	Booting/System Self-Test
		Red On	Device Ready
LAN	Link Yellow	Off	No Ethernet Link
		Green On	Ethernet Link established
RXD	Yellow	ON	Signal indication data receive
TXD	Green	ON	Signal indication data send

2.3 Initial Setup

Use this section to set up your computer to assign it a static IP address in the 192.168.168.1 to 192.168.168.254 range with a subnet mask of 255.255.255.0. This is necessary to ensure that your computer can communicate with your UT-620.


Your computer must have an Ethernet card and TCP/IP installed. TCP/IP should already be installed on computer using Windows 98/2000/XP and later operating systems.

Note: Connect a computer to UT-620 Ethernet port directly should be with crossover Ethernet cable, if both connect to hub/switch should be with straight-through Ethernet cable.

2.3.1 Installing the TCP/IP Protocol

If you are not sure whether the TCP/IP Protocol has been installed, follow these steps to check, and if necessary, install TCP/IP onto your PCs.


Step 1: Click the “**Start**” button. Choose “**Settings**”, then “**Control Panel**”. Double-click the “**Network Connections**” icon. Your Network window should appear as follows:



Step 2:

For **Windows 98 and Millennium**

On the “**Configuration**” tab (if using **Windows 98 and Millennium PCs**), select the **TCP/IP** line for the applicable Ethernet adapter. Do not choose a TCP/IP entry whose name mentions PPPoE, VPN. If the word **TCP/IP** appears by itself, select that line. Click the **Properties** button.



Important:


For Windows 2000 & Windows XP Setting, you will find that they differ with Windows 98/ME/NT slightly. See the following for reference.

For **Windows XP and Windows 2000**

Click the **“Local Area Connection”** icon on the lower right hand side of your desktop screen.



In the **“Local Area Connection Status”** window, click the **“Properties”** button then your Network window will appear.



There are two tabs, **“General”** and **“Support”**, in the Network window.


Step 3: Check whether the TCP/IP Protocol has already been installed onto your computer's Ethernet card. Note that TCP/IP Protocol can be installed for a computer's Dial-Up Adapter as well as for the Ethernet card.

- * If yes, go to section 2.3.2.
- * If no, click the **“Install”** button.

Step 4: Double-click **“Protocol”** in the Select Network Component Type or highlight **“Protocol”** then click **“Add”**.



Step 5: Highlight **“Microsoft”** under the list of manufacturers. Double-click **“TCP/IP”** from the list on the right or highlight **“TCP/IP”** then click **“OK”** to install TCP/IP.




Step 6: After a few seconds, you will be returned to the Network window. The TCP/IP Protocol should now be on the list of installed network components (see 3 above).

2.3.2 Fixed IP Addresses Configuration

For **Windows 98 and Millennium**


Step 1: To set up computers with fixed IP Addresses, click the **“Properties”** button. The TCP/IP Properties window consists of several tabs. Choose the **“IP Address”** tab as shown below.

Step 2: Select **“Specify an IP address”** and enter **“192.168.168.xxx”** (the default value of 450M is **192.168.168.125**) in the **“IP Address”** location (where xxx is a number between 1 and 254 used by the High-Performance UT-620 to identify each computer), and the default **“Subnet Mask” “255.255.255.0”**. Note that no two computers on the same LAN can have the same IP address.




For **Windows XP and Windows 2000**

Step 1: Make sure the box next to Internet Protocol (TCP/IP) is checked. Highlight **Internet Protocol (TCP/IP)**, and click the **Properties** button



Step 2: Select **“Specify an IP address”** and enter **“192.168.168.xxx”** (the default value of 450M is **192.168.168.125**) in the **“IP Address”** location (where xxx is a number between 1 and 254 used by the High-Performance UT-620 to identify each computer), and the default **“Subnet Mask” “255.255.255.0”**. Note that no two computers on the same LAN can have the same IP address.



Click **“OK”** . to complete the TCP/IP installation.


2.3.3 Configure your UT-620

Step 1: Open your web browser and type <http://192.168.168.125> in the browser's *address box*. This address is the factory set IP Address of your UT-620. Press "Enter".

Step 2: The "Username and Password required" prompt box will appear. Typing "admin" (default username) in the Username field and typing "admin" (default password) in the Password field. Click "OK". The setup screen will then appear.



Step 3: It is highly recommended you change the default username and password when you login successfully first time.



Step 4: Setup the Operation Mode for TCP/IP connection and Serial Type for connecting with your device.

Note: Don't forget click Apply button to save your changing when you complete your configuration setting each time, the UT-620 will restart automatically in 10 seconds with your new setting.

3. UT-620 Configuration Setup

This chapter will show you how to configure UT-620 to function in your network and gain access to your device through Intranet or Internet.

3.1 Operation mode

The UT-620 support four operation mode: TCP Server, TCP Client, UDP Server and UDP Client. These modes are listed in the drop-down menu for the Operation Mode setting. Each setup screen and available features will differ depending on what kind of operation mode you select. Default is TCP Server.

TCP Server

Operation Mode Setup (TCP Server)	
MODE: TCP SERVER	
Local Listen Port Number	50000
Close Connection When Remote Idle	10 (seconds)
Access Password	(maxlen 31)
Keep Alive Check	<input checked="" type="radio"/> Disable <input type="radio"/> Enable
Max TCP Connection	1

APPLY CANCEL BACK

Listen Port Number: default **50000**, range **0** to **65535**

If your device is acted as passive to accept commands from remote and the data be guaranteed to be received by peer is your concern, then you can set UT-620 as TCP Server. Be sure the value of item **Listen Port Number** is same as your remote control application using.

Close Connection When Remote Idle (second): default **300**, range **0** to **32768**

If you want to keep the connection between UT-620 and your remote control application always on, then set the value of item **Close Connection When Remote Idle** to 0, otherwise, when the idle time of no any traffic on line reach the setting value, UT-620 will terminate this connection.

TCP Client

Operation Mode Setup (TCP Client)	
MODE: TCP CLIENT	
Remote Connection Port Number	50000 (0 - 65535)
Remote Host IP Address	192 . 168 . 168 . 1
TCP Connection	<input checked="" type="radio"/> Start Up <input checked="" type="radio"/> Any Character

APPLY CANCEL BACK

Remote Connection Port Number: default **50000**, range **0** to **65535**

Remote Host IP Address: default **0.0.0.0**

If your device is acted as active to report real-time status to remote and the data be guaranteed to be received by peer is your concern, then you can set UT-620 as TCP Client. Be sure the value of item **Remote Connection Port Number** is same as your remote control application using and set the correct value of **Remote Host IP Address**.

UDP Server

Serial To Ethernet

Operation Mode Setup (UDP Server)

MODE: UDP SERVER

Local Listen Port Number: 50000 (0 - 65535)

APPLY CANCEL BACK

Listen Port Number: default **50000**, range **0** to **65535**

If your device is acted as passive to accept commands from remote and the data be guaranteed to be received by peer is *not* your concern, then you can set UT-620 as UDP Server. Be sure the value of item **Listen Port Number** is same as your remote control application using.

UDP Client

Serial To Ethernet

Operation Mode Setup (UDP Client)

MODE: UDP CLIENT

Remote Connection Port Number: 50000 (0 - 65535)

Remote Host IP Address: 0.0.0.0

APPLY CANCEL BACK

Remote Connection Port Number: default **50000**, range **0** to **65535**

Remote Host IP Address: default **0.0.0.0**

If your device is acted as active to report real-time status to remote and the data be guaranteed to be received by peer is *not* your concern, then you can set UT-620 as TCP Client. Be sure the value of item **Remote Connection Port Number** is same as your remote control application using and set the correct value of **Remote Host IP Address**.

3.2 IP Configuration

The UT-620 support three IP connection types: Static IP, DHCP and PPPoE. These types are listed in the drop-down menu for the IP Configuration setting. Each setup screen and available features will differ depending on what kind of IP connection types you select. Default is Static IP

Static (or Fixed) IP

One Page Quick Setup (Fixed IP)	
TYPE: STATIC IP	
IP Address	192 .168 .168 .125
Subnet mask	255 .255 .255 .0
Gateway	192 .168 .168 .254
Primary DNS	168 .95 .1 .1
Serial Port Mode	
Serial Type	RS232
Baud Rate	19200 (User Defined)
Operation Mode	
Connection Mode	TCP SERVER
Connection Port Number	50000
Remote Host IP Address (For Client Only)	0 .0 .0 .0
[APPLY] [CANCEL] [BACK]	

IP Address: default **192.168.168.125**

Subnet mask: default **255.255.255.0**

Gateway: default **192.168.168.254**

Primary DNS: default **168.95.1.1**

If you are connecting through a static or fixed IP from your network environment, perform these steps:

Step 1: Enter IP address

Step 2: Enter Subnet mask

Step 3: Enter Gateway IP address

Step 4: Enter Primary DNS IP address

Step 5: click Apply button

DHCP

Host Name (Optional): default **UTEK**, maximum length **15** characters

If there is a DHCP Server existing in your network environment or you subscribe a CABLE service from your ISP, you can set IP configuration to DHCP to get a dynamic IP address. The **Host Name** is an *optional* item, depending on your DHCP Server setting.

Note 1: to gain CABLE service, you also need to change the MAC address of UT-620 to the MAC address of register in ISP. Please refer to Chapter 4 Device Admin/Mac Address Change

PPPoE

User Name: no default, maximum length **47** characters

Password: no default, maximum length **35** characters

Service Name (optional): no default, maximum length **47** characters

Close Connection when Idle Time Over (second): default **0**, range **0** to **4294967295**

PPPoE with Fixed IP Address: default **DISABLE**

If you subscribe a DSL service with PPPoE connection from ISP, you can set IP configuration to PPPoE to get a dynamic IP address. Your ISP will provide you the **User Name** and **Password**, some ISP will also need the **Service Name** to authenticate. But this item is optional and depending on your ISP.

If you want to keep the connection always on between UT-620 and your ISP, then set the value of item **Close Connection When Idle Time Over** to 0, otherwise, when the idle time of no any traffic on line is over the setting value, UT-620 will terminate this PPPoE connection.

If your ISP can provide you fixed IP address when PPPoE connection established each time, you can select **PPPoE with Fixed IP Address** as ENABLE and enter the IP address given from ISP.

3.3 Serial Type

The UT-620 support three serial types: RS232, RS422 and RS485, These types are listed in the drop-down menu for the Serial Type setting. Each setup screen and available features will differ depending on what kind of Serial Types you select and UT-620 product model you buy. Default is RS232

RS232

Serial Port Setup	
Serial Type	RS232
Baud Rate	19200 0 (User Defined)
Data Bits	8
Parity Check	Space
Stop Bits	1
Flow Control	None
Force Packet Transmit Time	0 (0 - 65535)ms
Force Packet Transmit Length	0 (0 - 65535)bytes
Delimiter 1	0x00 (HEX) <input type="radio"/> Enable <input checked="" type="radio"/> Disable
Delimiter 2	0x00 (HEX) <input type="radio"/> Enable <input checked="" type="radio"/> Disable
RS485 Transmission Delay Time	0 (0 - 65535)us Note: for RS485 only

APPLY CANCEL BACK

Baud Rate: default **115200**, range 1200bps to 230.4Kbps

Data Bits: 5, 6, 7, **8** (default)

Parity Check: **None** (default), even, odd

Stop Bits: **1** (default), 2

Flow Control: **None** (default), CTS/RTS (or Hardware), XON/XOFF (or Software)

Force Packet Transmit Time (ms): default **40**, range **20** to **65535**

The timing of transmitting an Ethernet packet, in order to get the whole data in on packet, you can tune this setting value to fit the data length of your device per transmission. The more small value be set will get more less data in one packet.

RS422

The settings are similar with RS232.

RS485

RS485 Transmission Delay Time (ms): default **0**, range **0** to **65535**

Due to different device has different capability in handling data received from serial port. So you can tune this setting value to slow down the speed of UT-620 to fit the speed of your device handling.

3.4 Dynamic DNS

The UT-620 offers a Dynamic Domain Name System (DDNS) feature. DDNS lets you assign a fixed host and domain name to a dynamic Internet IP address. It is useful when you want to access your device through Internet without static IP address. Before you can use this feature, you need to sign up for DDNS service at www.dyndns.org or www.tzo.com, two DDNS service provider. This service default is disabled.

If your DDNS service is provided by DynDNS.org, then select **DynDNS** in the drop-down menu. If your DDNS service is provided by TZO, then select **TZO**. The features available on the DDNS screen will vary, depending on which DDNS service provider you use. (Detail sees Appendix B)

Dyndns.org

DDNS Setup	
DDNS Services:	dyndns
Username:	<input type="text"/> (maximum 31)
Password:	<input type="password"/> (maximum 31)
Device DNS Name:	<input type="text"/> (ex. hostname.dyndns.org) (maximum 47)
Registry IP Address :	192.168.168.125
Status :	DDNS function is disabled
<input type="button" value="APPLY"/> <input type="button" value="CANCEL"/> <input type="button" value="BACK"/>	

User Name: no default, maximum length **31** characters

Password: no default, maximum length **31** characters

Device DNS Name: no default, maximum **47** characters

Enter the **User Name, Password, and Device DNS Name** of the account you set up with DynDNS.org. Registry IP Address. The UT-620's current Internet IP Address is displayed here. Because it is dynamic, it will change.

Status. The status of the DDNS service connection is displayed here.

Tzo.com

DDNS Setup

DDNS Services: TZO

Email Address:	<input type="text"/> (maximum 47)
Password key:	<input type="text"/> (maximum 31)
Device DNS Name:	<input type="text"/> (ex. hostname.tzo.com)
Registry IP Address :	192.168.168.125
Status :	DDNS function is disabled

APPLY | CANCEL | BACK

Email Address: no default, maximum length **47** characters

Password key: no default, maximum length **31** characters

Device DNS Name: no default, maximum **47** characters

Enter the **Email Address**, **Password Key**, and **Device DNS Name** of the service you set up with TZO.

Registry IP Address. The UT-620's current Internet IP Address is displayed here. Because it is dynamic, this will change.

Status. The status of the DDNS service connection is displayed here.

4. UT-620 Management Setup

This chapter will show you how to manage UT-620's access setting as well as configure E-mail alert and firmware upgrade.

4.1 Device Admin

Device Administration Setting

Block Standard Http Port(80) Management UNBLOCK BLOCK

Device Management IP Address: 192 .168 .200 .200

Device Hostname: JUTEK

Device Location:

Administrator Password: User Name
 Password Change
 Password Confirm

Block Ping Request UNBLOCK BLOCK

MAC Address Change: :00 :00 :00 :00 :00 :00

Reset System to Factory Default

Reboot System

BACK

Block Standard HTTP Port(80) Management: default **UNBLOCK**

If for some reason, the HTTP (80) service is blocked in your network environment and result to fail to configure or manage UT-620, then you select **BLOCK** this function with using port **8080**, instead of standard port 80. So you should enter: <http://192.168.168.125:8080> in your browser.

Device Management IP Address: default **192.168.1.10**

In case, you forgot the UT-620's IP address you ever set, this management IP can be used to connect to UT-620 to figure out what's the current IP address be used.

In case, you set UT-620's IP Configuration as DHCP or PPPoE which will assign dynamic IP address to UT-620, you also can use this management IP address to find what's the current working IP address in Intranet.

Note: If you forgot the IP address setting even management IP address, please use the broadcast utility we offer in CD to search it.

Device Hostname: default **UTEK**, maximum length **15** characters

To describe the name of UT-620 for manage purpose.

Device Location: no default, maximum length **15** characters

To describe the location of UT-620 for manage purpose.

Administrator Password

User Name: default **admin**

Password: default **admin**

To ensure the UT-620's security, you will be asked for your password when you access the UT-620's Web-based Utility.

User Name: Enter the user name to one of your choice.

Password: It is recommended that you change the default password to one of your choice.

Password Confirm: Re-enter the UT-620's new Password to confirm it.

Block Ping Request: default **UNBLOCK**

To prevent hacker intruding your network, check the **BLOCK** option to enable this function to reject the PING requests from Internet.

MAC Address Change

The UT-620's MAC address can be changed from the original values if necessary. Some ISPs require users to change the MAC address to a registered one when users change their access equipment. (Detail sees Appendix B)

Reset System to Factory Default

Click "**Apply**", if you want to return all the UT-620's current settings to its factory default. *Note: do not restore the factory defaults unless it is absolutely necessary.*

Reboot System

Click "**Apply**", if you want to clear a connection, reboot, and re-initialize the unit without affecting any of your configuration setting.

4.2 Device Status

This screen shows the UT-620's current status. All of the information provided is read-only.

System Status	
Product Name:	232485 To TCP/IP Converter
Firmware Version:	1.04.05.Aug 30 2005
System Up Time:	4H56M27S

Ethernet Status	
IP Configuration Mode:	STATIC IP
Operation Mode:	TCP SERVER
Connection Port:	50000
MAC Address:	00.0e.e3.00.13.ee
IP Address:	192.168.168.125
Subnet mask:	255.255.255.0
Default Gateway:	192.168.168.254
Primary DNS:	168.95.1.1
STATUS:	Up

Serial Status	
Serial Type:	RS232
Baud Rate:	19200
Data Bits:	8
Parity Check:	none
Stop Bits:	1
Flow Control:	None

Statistic	
Ethernet :	TX Bytes: 48994 bytes
	TX Packets: 84 packets
	RX Bytes: 399658 bytes
	RX Packets: 4457 packets
Serial:	TX Bytes: 0 bytes
	RX Bytes: 0 bytes

Product Name: the product model name of this UT-620.

Firmware Version: the installed version of the firmware.

System up Time: the time of system from start up to current.

Management IP Address: the current setting of management IP.

Ethernet Status: the UT-620's IP Configuration, MAC address, IP address, subnet mask, default gateway IP address, primary DNS IP address and current connection status.

Serial Status: the UT-620's setting in serial type

Statistic: the transmission and receive bytes and packets count in Ethernet and Serial port separately.

4.3 E-Mail Alert

The UT-620 allows you send E-Mail to alert the event of I/O state changing. This service default is disabled.

E-mail Alert: default **DISABLE**

Domain Name (optional): no default, maximum length **59** characters

SMTP Mail Server: no default, maximum length **27** characters

E-mail Alerts To: no default, maximum length **27** characters

Return Address: no default, maximum length **27** characters

Select **ENABLE** in **E-mail Alert**

Enter the **Domain Name** in this field if needed. **(this is optional)**


Enter the **SMTP Mail Server** in the field.

Enter the e-mail account you want to reach or notice in the field of **E-mail Alerts To**.

Enter the e-mail account you want to return in the field of **Return Address**.

4.4 Backup and Restore

This function allows you to save UT-620's configuration as backup, or retrieve the configuration file you saved before to turn the setting back.




Backup: Click "Backup" button save the current configuration as a backup file in your hard disk.

Restore: Enter path of the configuration file you saved on the PC. You can click "Browse" to view the folders and select the file. Click "Restore" to retrieve it.

Note: the sub-name of file you retrieve must be ".cfg"

4.5 Upgrade Firmware

This function allows you to upgrade the latest version firmware to keep your UT-620 up-to-date. Before you upgrade the firmware, you have to get the latest firmware and save it on the PC you use to configure the UT-620.




Browse: To select a file to upgrade, you have to enter path of the latest firmware you saved on the PC. You can choose “**Browse**” to view the folders and select the firmware.

Upgrade: After you enter or select the path, click “**Upgrade**” to start the firmware upgrade process.

Note: *don't power off the router during the firmware upgrading, otherwise the incompleteness of firmware upgrading will cause serious damage to the integrity of the UT-620's firmware that will lead to fail to boot the UT-620 again.*

4.6 Ping

This function allows you to test the connection between UT-620 and LAN or between UT-620 and Internet.



Source IP Address: the current UT-620's IP address (Read Only).

Destination IP Address: the IP Address of destination device you want to ping.

Packet Number: the packet numbers you wish to use to ping the destination device. The maximum numbers are 4.

Packet Size: the numbers of packet size you wish to use to ping the destination device. The maximum packet sizes are 1400.

Ping Result: The result will show the numbers of sending packet, numbers of packet receiving (Read Only).

5. Troubleshooting

PROBLEM	CORRECTIVE ACTION
None of the LEDs turn on when you turn on the UT-620	Make sure that you have correct power connected to UT-620 and plugged in to an appropriate power source. Check all cables connections. If the LEDs still do not turn on, you may have a hardware problem. In this case, you should contact your local vendor.
Can not access UT-620 from Ethernet	Check cable connection between UT-620 and computer or hub. Ping UT-620 from computer. Make sure your computer Ethernet card is installed and functioning properly.
Can not ping any computer on the LAN	If the 10/100M LED are off, check the cable connection between UT-620 and your computer. Verify that the IP address and subnet mask of the UT-620 and computer are in the same IP address range.
Can not access UT-620 from Serial	Check the Serial cable connection between UT-620 and your device. Verify that the UT-620 setting of Serial type is same as your device and make sure the hardware jumper is in the correction position.

Appendix B: DDNS


Internet actually runs on IP Addresses which are numerical order, for example "63.208.196.100". These IP Address identify the location of each device connected to Internet. However, the human brain does not easily remember this numbering system, so a system that allocate domain name such as "www.dyndns.org" provides an easier method. If you type "63.208.196.100" or "www.dyndns.org" in the web browser's address bar, the browser will show the same web page. This is because both methods relate to the same web server. The "**Domain Name Servers**" used to manage the Internet will translate "www.dyndns.org" into the IP Address "63.208.196.100" in order to allow your browser to find the web server and display the correct web page in your browser.

If your "IP Configuration", as shown in 3.2 section, is "PPPoE", or "DHCP" with dynamic IP address assigned by ISP, your IP address may change each time you initiate the connection to your ISP. The DDNS function will help to map your IP address to your domain name when your ISP assigns a new dynamic IP Address.


Note that this DDNS function acts as the client appliance of DDNS service and is only able to be use in conjunction with the service provided by DynDNS.org and TZO.com. Before you begin using this function, you will need to apply to DynDNS.org or TZO.com to be able to use the service. Please visit www.dyndns.org or www.tzo.com for further information.

How to register from DynDNS.org


Step 1: Enter the web side www.dyndns.org in Browser, click the tab of **Account**.




Step 2: click **Create Account**.




Step 3: Fill the field of Username , E-mail and Password. You will receive an e-mail containing instructions to activate your account.




Step 4: Once you receive the confirmed e-mail, **login** with your Username and Password.




Step 5: Click the tab of **Services**, then click **Dynamic DNS**.




Step 6: select **Add Host** in the left side of screen.



Step 7: Login again with your **Username** and **Password**.



Step 8: Enter the **Hostname** you want to use and select **dyndns.org** from the drop-down menu, click the button of **Add Host** to finish register.




Step 9: now you should enter the Username, Password and Hostname (named Device DNS Name in UT-620) into UT-620 to enable this function.

How to register from TZO.com

Step 1: Enter the web side www.tzo.com in Browser, select the **Order/Renew** from top screen.



Step 2: You can choice what's kind of service you need, here we suggest the **Standard TZO** with 1 year of service



Step 3: Select the first radio button, click **Continue** button.

TZO.COM

home domains control panel about us

Order/Renew | Download | Products | Support

Order/Renew

TZO secure order system total \$24.95 number of items 1

How did you get our TZO client software?
(If you don't have it yet, [click here to download it now.](#))

From the TZO download site or from another download site such as Tucows, WebAttack, etc.

It's included with my Nexland router.

From the CD included with my Linksys product.

It's included with my Serv-U FTP server.

It's included in my E-Tech, Ugate, Equinox Internet Broadband Gateway/router.

From the download site that Linksys directed me to

Continue

Step 4: Enter the TZO name you want to register, such as UTEK.tzo.com, and your E-mail address which can reach you. If you don't have a TZO name yet, please check the box under the field of E-mail address, click **Continue with order**

TZO.COM

home domains control panel about us

Order/Renew | Download | Products | Support

Order/Renew

TZO secure order system total \$24.95 number of items 1

Please complete the first step by telling us the following information

What is your TZO name?

What email address did you use when you registered your TZO name?
(Windows users can find this information in the TZO client. Linux users can look in the configuration file.)

I don't have a TZO name yet, or I'm not certain what it is.

PLEASE NOTE:
A TZO name is a sub-domain of TZO.COM, TZO.NET, or other domains which are listed in the TZO client. Please mail support@TZO.COM if you have questions.
If you don't have a TZO name, you should register and get a TZO name before you go any further. You can [Download TZO](#) or use the [TZO Control Panel](#) to register and get a TZO name. You'll need a TZO name to use most of our services!

Continue with order

Step 5: complete the form with your information TZO want.

Order/Renew

TZO secure order system total \$24.95 number of items 1

Please complete the first step by telling us the following information

Next, please tell us about yourself, and please include all the information. We ask you nothing more than what's necessary for us to process your order.

For your address please use your current credit card or bank billing address. (The address where your credit card or bank statements are sent each month)

WHY USE TZO ?

- It's Reliable
- Doesn't use BIND
- Free Support

TZO Awards/Reviews

- TZO Awards
- Editorial reviews
- Customer Comments

Your first name:

Your last name:

Your company name: (if applicable)

Street address: (the billing address of the credit card)

Address 2: (the billing address of the credit card)

City: (the billing address of the credit card)

Step 6: TZO will send an e-mail letter to inform your TZO key, please enter these information including E-mail address, TZO key and TZO name (named Device DNS Name in UT-620) into UT-620 to enable this service.

Appendix C: Glossary

10BaseT - An Ethernet standard that uses twisted wire pairs.

100BaseTX - IEEE physical layer specification for 100 Mbps over two pairs of Category 5 UTP or STP wire.

Adapter - Printed circuit board that plugs into a PC to add to capabilities or connectivity to a PC. In a networked environment, a network interface card (NIC) is the typical adapter that allows the PC or server to connect to the intranet and/or Internet.

Auto-MDI/MDIX - On a network hub or switch, an auto-MDI/MDIX port automatically senses if it needs to act as a MDI or MDIX port. The auto-MDI/MDIX capability eliminates the need for crossover cables.

Auto-negotiate - To automatically determine the correct settings. The term is often used with communications and networking. For example, Ethernet 10/100 cards, hubs, and switches can determine the highest speed of the node they are connected to and adjust their transmission rate accordingly.

Browser - A browser is an application program that provides a way to look at and interact with all the information on the World Wide Web or PC. The word "browser" seems to have originated prior to the Web as a generic term for user interfaces that let you browse text files online.

Cable Modem - A device that connects a computer to the cable television network, which in turn connects to the Internet. Once connected, cable modem users have a continuous connection to the Internet. Cable modems feature asymmetric transfer rates: around 36 Mbps downstream (from the Internet to the computer), and from 200 Kbps to 2 Mbps upstream (from the computer to the Internet).

CAT 5 - ANSI/EIA (American National Standards Institute/Electronic Industries Association) Standard 568 is one of several standards that specify "categories" (the singular is commonly referred to as "CAT") of twisted pair cabling systems (wires, junctions, and connectors) in terms of the data rates that they can sustain. CAT 5 cable has a maximum throughput of 100 Mbps and is usually utilized for 100BaseTX networks.

CTS (Clear To Send) - An RS-232 signal sent from the receiving station to the transmitting station that indicates it is ready to accept data.

Data Packet - One frame in a packet-switched message. Most data communications is based on dividing the transmitted message into packets. For example, an Ethernet packet can be from 64 to 1518 bytes in length.

Default Gateway - The routing device used to forward all traffic that is not addressed to a station within the local subnet.

Download - To receive a file transmitted over a network. In a communications session, download means receive, and upload means transmit.

Dynamic IP Address - An IP address that is automatically assigned to a client station in a TCP/IP network, typically by a DHCP server. Network devices that serve multiple users, such as servers and printers, are usually assigned static IP addresses.

Ethernet - IEEE standard network protocol that specifies how data is placed on and retrieved from a common transmission medium. Has a transfer rate of 10 Mbps. Forms the underlying transport vehicle used by several upper-level protocols, including TCP/IP and XNS.

DDNS (Dynamic Domain Name System) - Allows a network device with a dynamic Internet IP address to have a fixed host and domain name, such as *myhostname.mydomainname.com*. It is useful when you are hosting your own website, FTP server, or other server behind a router, so people can find your site no matter how often the Internet IP address changes. Using DDNS requires registering with a DDNS service provider on the Internet.

DHCP (Dynamic Host Configuration Protocol) - A protocol that lets network administrators centrally manage and automate the assignment of Internet Protocol (IP) addresses in an organization's network. Using the Internet's set of protocol (TCP/IP), each machine that can connect to the Internet needs a unique IP address. When an organization sets up its computer users with a connection to the Internet, an IP address must be assigned to each machine. Without DHCP, the IP address must be entered manually at each computer and, if computers move to another location in another part of the network, a new IP address must be entered. DHCP lets a network administrator supervise and distribute IP addresses from a central point and automatically sends a new IP address when a computer is plugged into a different place in the network. DHCP uses the concept of a "lease" or amount of time that a given IP address will be valid for a computer. The lease time can vary depending on how long a user is likely to require the Internet connection at a particular location. It's especially useful in education and other environments where users change frequently. Using very short leases, DHCP can dynamically reconfigure networks in which there are more computers than there are available IP addresses. DHCP supports static addresses for computers containing Web servers that need a permanent IP address.

DNS - The Domain Name System (DNS) is the way that Internet domain names are located and translated into Internet Protocol (IP) addresses. A domain name is a meaningful and easy-to-remember "handle" for an Internet address.

Domain - A sub network comprised of a group of clients and servers under the control of one security database. Dividing LANs into domains improves performance and security.

Firmware - Code that is written onto read-only memory (ROM) or programmable read-only memory (PROM). Once firmware has been written onto the ROM or PROM, it is retained even when the device is turned off.

Full Duplex - The ability of a device or line to transmit data simultaneously in both directions.

Gateway - A device that interconnects networks with different, incompatible communications protocols.

Half Duplex - Data transmission that can occur in two directions over a single line, but only one direction at a time.

Hardware - Hardware is the physical aspect of computers, telecommunications, and other information technology devices. The term arose as a way to distinguish the “box” and the electronic circuitry and components of a computer from the program you put in it to make it do things. The program came to be known as the software.

Hub - The device that serves as the central location for attaching wires from workstations. Can be passive, where there is no amplification of the signals; or active, where the hubs are used like repeaters to provide an extension of the cable that connects to a workstation.

HTTP (HyperText Transport Protocol) - The communications protocol used to connect to servers on the World Wide Web. Its primary function is to establish a connection with a Web server and transmit HTML pages to the client browser.

MAC Address - The MAC (Media Access Control) address is a unique number assigned by the manufacturer to any Ethernet networking device, such as a network adapter, that allows the network to identify it at the hardware level.

Mbps (MegaBits Per Second) - One million bits per second; unit of measurement for data transmission.

IP Address - In the most widely installed level of the Internet Protocol (IP) today, an IP address is a 32-binary digit number that identifies each sender or receiver of information that is sent in packets across the Internet. When you request an HTML page or send e-mail, the Internet Protocol part of TCP/IP includes your IP address in the message (actually, in each of the packets if more than one is required) and sends it to the IP address that is obtained by looking up the domain name in the Uniform Resource Locator you requested or in the e-mail address you're sending a note to. At the other end, the recipient can see the IP address of the Web page requestor or the e-mail sender and can respond by sending another message using the IP address it received.

IPCONFIG - A utility that provides for querying, defining and managing IP addresses within a network. A commonly used utility, under Windows NT and 2000, for configuring networks with static IP addresses.

ISP - An ISP (Internet service provider) is a company that provides individuals and companies access to the Internet and other related services such as website building and virtual hosting.

Packet - A unit of data routed between an origin and a destination in a network.

Network Mask - Also known as the “Subnet Mask.”

NIC (Network Interface Card) - A board installed in a computer system, usually a PC, to provide network communication capabilities to and from that computer system. Also called an adapter.

RJ-45 - A connector similar to a telephone connector that holds up to eight wires, used for connecting Ethernet devices.

Server - Any computer whose function in a network is to provide user access to files, printing, communications, and other services.

SMTP (Simple Mail Transfer Protocol) - The standard e-mail protocol on the Internet. It is a TCP/IP protocol that defines the message format and the message transfer agent (MTA), which stores and forwards the mail.

Ping (Packet INternet Groper) - An Internet utility used to determine whether a particular IP address is online. It is used to test and debug a network by sending out a packet and waiting for a response.

Port - A pathway into and out of the computer or a network device such as a switch or router. For example, the serial and parallel ports on a personal computer are external sockets for plugging in communications lines, modems, and printers.

PPPoE (Point to Point Protocol over Ethernet) - PPPoE is a method for the encapsulation of PPP packets over Ethernet frames from the user to the ISP over the Internet. One reason PPPoE is preferred by ISPs is because it provides authentication (username and password) in addition to data transport. A PPPoE session can be initiated by either a client application residing on a PC, or by client firmware residing on a modem or router.

Subnet Mask - The method used for splitting IP networks into a series of subgroups, or subnets. The mask is a binary pattern that is matched up with the IP address to turn part of the host ID address field into a field for subnets.

TCP (Transmission Control Protocol) - A method (protocol) used along with the IP (Internet Protocol) to send data in the form of message units (datagram) between network devices over a LAN or WAN. While IP takes care of handling the actual delivery of the data (routing), TCP takes care of keeping track of the individual units of data (called packets) that a message is divided into for efficient delivery over the network. TCP is known as a "connection oriented" protocol due to requiring the receiver of a packet to return an acknowledgment of receipt to the sender of the packet resulting in transmission control.

TCP/IP (Transmission Control Protocol/Internet Protocol) - The basic communication language or set of protocols for communications over a network (developed specifically for the Internet). TCP/IP defines a suite or group of protocols and not only TCP and IP.

Telnet - A terminal emulation protocol commonly used on the Internet and TCP/IP-based networks. It allows a user at a terminal or computer to log onto a remote device and run a program.

TFTP (Trivial File Transfer Protocol) - A version of the TCP/IP FTP protocol that has no directory or password capability.

Static IP Address - A permanent IP address that is assigned to a node in a TCP/IP network.

Appendix D: Finding the MAC Address and IP Address for Your Ethernet Adapter

This section describes how to find the MAC address for your computer's Ethernet adapter so you can use the MAC address change feature of the UT-620. You can also find the IP address of your computer's Ethernet adapter. This IP address is used for the UT-620's configuration. Follow the steps in this appendix to find the adapter's MAC or IP address in Windows 98, Me, 2000, or XP.

1. Click **Start** and **Run**. In the *Open* field, enter **cmd**. Press the **Enter** key or click the **OK** button.
2. At the command prompt, enter **ipconfig /all**. Then press the **Enter** key.
3. Write down the Physical Address as shown on your computer screen (Figure D-1); it is the MAC address for your Ethernet adapter. This appears as a series of numbers and letters.
The MAC address/Physical Address is what you will use for MAC address changing.

The example in Figure D-1 shows the Ethernet adapter's IP address as 192.168.168.100. Your computer may show something different.

```
命令提示字元
C:\Documents and Settings\Chang>
C:\Documents and Settings\Chang>
C:\Documents and Settings\Chang>
C:\Documents and Settings\Chang>ipconfig /all

Windows IP Configuration

    Host Name . . . . . : eric
    Primary Dns Suffix . . . . . :
    Node Type . . . . . : Unknown
    IP Routing Enabled. . . . . : Yes
    WINS Proxy Enabled. . . . . : Yes

Ethernet adapter 區域連線:

    Connection-specific DNS Suffix . :
    Description . . . . . : National Semiconductor DP83815-Based
    PCI Fast Ethernet Adapter
    Physical Address. . . . . : 00-0D-9D-85-0C-E6
    Dhcp Enabled. . . . . : No
    IP Address. . . . . : 192.168.168.100
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . :
```

Figure E-1 MAC Address/Physical Address